


EMS3- SENDER SETUP

STEP 1

Before beginning installation, with no power to unit, set the DIP SWITCH POSITION on the unit.
Refer to picture on right and table below.





STEP 2

When first powered up, via the Menu, input the SENDER TYPE you are using below.
Refer to table below.



Resistive type senders
– DIP switch ON

Voltage type senders
– DIP switch OFF

CHANNEL #	WIRE COLOUR	MEASURING	SENDER TYPE	SENDER PICTURE	DIP SWITCH POSITION	SENDER TYPE
1	Green	Coolant Temp	RESISTIVE		ON	VDO 150
2	Yellow	Oil Temp	RESISTIVE		ON	LM335
3	Grey	Oil Pressure	VOLTAGE		OFF	SENDO / MPS7
4	Blue	Boost Pressure	VOLTAGE		OFF	SENDO / MPS2

Any of the four channels can measure Resistive or Voltage based senders