



RPM (Revs Per Minute) Alternator W terminal location for RPM



STEP 1

Find the W+ terminal on your alternator by opening the rear cover of alternator, eg below is for a TD5.



Open alternator rear cover



The lug pictured is the W+ terminal

STEP 2

*In the RPM setup, there is a K factor - this value is a divider.
Adjust the value until the real RPM matches the display.
You can use decimals.*

Discovery 300 TDI = 19,5